

TTHotel User Manual V1.1

2020.12.31



Content

1. Introduction	3 -
2. Windows Desktop Software	5 -
2.1. Login	5 -
2.1.1. Create hotel	6 -
2.2. Console	8 -
2.2.1. Buildings	9 -
2.2.2. Floors	11 -
2.2.3. Console (Guest room)	13 -
2.2.4. Check-in	15 -
2.2.5. Guest Information	17 -
2.2.6. Check-out	21 -
2.2.7. Modify check-out	22 -
2.2.8. Additional access	24 -
2.2.9. Add roommate	25 -
2.2.10. Clean/Dirty room	26 -
2.2.11. Room information	27 -
2.2.12. Records	28 -
2.2.13. Search for a room	29 -
2.2.14. Filter with status	30 -
2.2.15. View/Cancel/Renew card	31 -
2.3. Hotel	32 -
2.3.1. Hotel information	33 -
2.3.2. Rooms	34 -
2.3.3. Message	38 -
2.4. Staff	39 -
2.4.1. Roles	40 -
2.4.2. Create staff	41 -
2.4.3. Grant access	42 -
2.4.4. Staff detail	43 -
2.5. Guests	44 -
2.6. Access	45 -
2.6.1. Card	46 -



2.6.2. eKey(APP)	47 -
2.6.3. Passcode	48 -
2.7. Devices	49 -
2.7.1. Lock	50 -
2.7.2. Gateway	51 -
2.7.3. Lift controller	52 -
2.7.4. Power saver	52 -
2.8. Settings	53 -
2.8.1. Change account	55 -
2.8.2. Change password	56 -
2.8.3. Language	56 -
2.8.4. FAQs	57 -
3. Hotel APP	58 -
Scan QR code to install hotel APP	58 -
3.1. Login	59 -
3.2. Statistics	60 -
3.3. Devices	60 -
3.3.1. Lock	62 -
3.3.2. Gateway	66 -
3.3.3. Lift controller	68 -
3.3.4. Power saver	70 -
3.4. My ekeys	72 -
3.5. Me	73 -
3.5.1. Personal	73 -
3.5.2. Hotel management	75 -
4. Guest APP	75 -
4.1. Login	77 -
4.2. Operate on lock/lift/power saver	78 -



1. Introduction

TTHotel is a system for hotel/apartment/school management. People use it to issue cards, passcodes, and ekeys.

TTHotel manages buildings, floors, rooms, guests and staff.


TTHotel manages various devices, such as smart lock, lift controller, card encode, gateway.

TTHotel system includes a Windows desktop software which is used to issue card, a hotel app which is used to manage devices, a guest app which is used to unlock with phone.



2. Windows Desktop Software

2.1.Login




Login or create a new hotel in this page. You can also find APP QR code at and save them to your computer.


Only the administrator and staff accounts are allowed to login. One account is only valid in one hotel.



2.1.1. Create hotel









Please ask your lock supplier for the supplier code. Every hotel needs a lock supplier.



2.2. Console






The console includes Menu, Buildings, Floors, Rooms and Operations.




2.2.1. Buildings



Create, Edit, and Delete buildings here.




2.2.1.1. Create building



Click + to create a new building. The name should be unique


2.2.1.2. Edit building



shows up when put mouse on a building. Click it to edit or delete this building.




2.2.1.3. Delete building



Please delete devices first before deleting buildings. Floors and rooms in this building will also be deleted automatically:


2.2.2. Floors



Create, Edit and Delete floors here



2.2.2.1. Create floor



Click ⁺ to create a new floor. The name should be unique.


2.2.2.2. Edit floor



shows up when put mouse on a floor. Click it to edit or delete this floor.




2.2.2.3. Delete floor



Please delete devices first before deleting floors. Rooms in this floor will also be deleted automatically:

2.2.3. Console (Guest room)




There are all buildings, floors and guest rooms in console.



- This icon means there is no lock in this room.
- This icon mean it is a dirty room.

Public doors are not shown in console. You can select public doors for a guest room at check-in. And it will be remembered. You don't need to select public doors every time.


2.2.3.1. Create guest room




You can create guest rooms in single or batch. The name should be unique.



2.2.4. **Check-in**







Click on an unoccupied room to do check-in.

You can only do check-in for rooms which have smart locks. There will be a • on the room if there is no smart lock.

You are able to select additional common locks when issue card for a guest room.


In this way, this card can unlock both room and selected common locks.


When you issue card next time, the selected common locks will also be selected by default, so you don't need to select them every time manually.

Mifare card with 13.56MHz is allowed in TTHotel system. Sectors from 1 to 10 will be used for unlocking



2.2.5. Guest Information






You can check guest's information in the room. You can also edit the information, grant new access, add roommate, renew and check-out.




2.2.5.1. Edit guest information



You can change the name and contact information. The guest should login with new contact if he/she has an ekey.



2.2.5.2. Guest Detail



You can look up all guest information here. If the guest lost his card, you can mark it as loss or report loss.


Mark as loss: The card will be marked as a lost card in system. When issue a new card, the new card will invalidate the lost card when put it on the lock.

Report loss: Create a new card and put it to the lock to invalidate the lost card.

The invalidated card will never be available again, please pay attention.




2.2.5.3. Grant new access




You can grant new access to current guests. One guest can have multiple access.



2.2.6. Check-out





Click on an occupied room to do check-out.




If the access is a card, you will be asked to cancel card when doing check-out. This can be skipped if the card is not available at this moment.

If the access is an ekey, it will be deleted automatically.


If the access is a passcode, it will not be deleted except there is a gateway.

The room status will be dirty after check-out.

2.2.7. Modify check-out







You can do this on an occupied room.


If the access is a card, you will be asked to renew card.


If the access is an ekey, it will be renewed automatically.

If the access is a passcode, it will not be renewed except there is a gateway.



2.2.8. Additional access







You can grant a new access to current guest. It can be card, APP or passcode.



2.2.9. Add roommate







Roommates share the same time period



2.2.10. Clean/Dirty room







You can set the room status from the menu



2.2.11. Room information






The information includes building, floor, type and price



2.2.12. Records




Look up all unlock records here.

If the lock is connected to a gateway, records will be shown in this list automatically. If there is no gateway, you need to collect records with hotel app near the lock.




2.2.13. Search for a room



Search with room number




2.2.14. Filter with status



Filter rooms with status occupied, unoccupied, dirty



2.2.15. View/Cancel/Renew card




View card: look up permission in the card

Cancel card: clear permission and loss information in the card. The room will also be check-out.

Renew card: Renew the valid period, also modify the check-out




2.3. Hotel



It includes Information, Rooms, and Message



2.3.1. Hotel information



You can edit hotel name or delete a hotel here.


You can select which kinds of access are allowed in your hotel: card, app, passcode

You decide if the guest card override privacy mode. It is OFF by default.

You can see which sectors of card are used. The rest sectors can be used for other purposes.




2.3.2. Rooms



There are two types of rooms: Guest room and common room. When issue card for guest room, you can select additional common rooms.




2.3.2.1. Create/Edit/Delete room type



Create, Edit or Delete room type in this page: Room -> room type management




2.3.2.2. Create/Edit/Delete guest room



You should delete devices first before deleting rooms.




2.3.2.3. Create/Edit/Delete common room



Manage common room is this page: Rooms->common room



2.3.3. Message




Look up all types of messages here.

Messages include low battery notification, locks being deleted, and etc




2.4.Staff




Manage staff in this page.



2.4.1. Roles






Manage roles and their permission here.




2.4.2. Create staff



Create a staff with unregistered account




2.4.3. Grant access




You can grant different kind of access here, including card, app, passcode.



2.4.4. Staff detail






Look up staff information and their granted access. The admin can transfer the hotel to a new account.




2.5. Guests



Look up history guests




2.6. Access



Access includes cards, ekeys, and passcodes



2.6.1. Card




Card list, including guest card, staff card.

When a card lost, you can "report loss" or "mark as loss" here.




2.6.2. eKey(APP)



The ekey list includes all ekeys issued to staff and guests.




2.6.3. Passcode



Passcode list. The passcode can only be managed via phone Bluetooth or gateway.




2.7. Devices



Manage locks, gateways, lift controller and power saver here.




2.7.1. Lock




Lock management. You can see lock operation records here.



2.7.2. Gateway






Gateway management. You can look up connected locks.




2.7.3. Lift controller



Lift controller management. You can see their working mode here.




2.7.4. Power saver



Power saver management. You can see their working mode here.




2.8. Settings




Manage account, password, language and etc



2.8.1. Change account






Replace your current account with a new one.



2.8.2. Change password



Chang your login password




2.8.3. Language



Switch software language

2.8.4. FAQs



Find answers for frequently asked questions




3. Hotel APP



Scan QR code to install hotel APP




3.1.Login



Only account with APP access permission can login hotel app.




3.2. Statistics



Only administrator and staff with this permission can see the statistics information.



3.3. Devices




Manage locks, gateways and lift controllers here.


Click [+] to add devices




3.3.1. Lock

3.3.1.1. Add











You can only add locks which work with hotel system. Not all locks.




3.3.1.2. settings









Staff with permission can configure devices and grant access here.

You can also manage card, ekeys, passcodes here.


3.3.1.3. Delete/Remove devices

You can delete a lock via phone Bluetooth near the lock. Make sure there is no guest in this room.



3.3.2. Gateway

3.3.2.1. Add






Click [+] to add gateway



3.3.2.2. settings




3.3.2.3. Delete

Gateways can be deleted from network



3.3.3. Lift controller


3.3.3.1. Add



Configure floor information to lift controller, and set the working mode.



3.3.3.2. **settings**



You can set working mode and configure floor information here


3.3.3.3. Delete/Remove devices

You can only delete lift controller via phone Bluetooth near to it.



3.3.4. Power saver

3.3.4.1. Add






Insert a card to activate the power saver, then add it with app.



3.3.4.2. **Settings**






Staff with permission can configure the lift controller here.

3.3.4.3. Delete

Delete it via phone Bluetooth near to it.



3.4. My ekeys




Administrator has ekeys for all locks in hotel

Staff has ekeys granted to him

Ekey is used to unlock with phone




3.5.Me





3.5.1. Personal




3.5.1.1. Edit account

Replace current account with a new one



3.5.2. Hotel management



Staff with permission can manage hotel information here.




4. Guest APP



Scan QR code to install Guest APP



4.1.Login



Guest can only login to this app when hotel send him an ekey.



4.2. Operate on lock/lift/power saver





